


Instruction manual

imitation buttonhole sewing machine

Read the instruction carefully before operation

Please keep the instruction appropriately








brief

Welcome to using our specialized sewing machine controller, please note to read the instruction manual carefully to ensure the proper operation. We have no responsibilities on any loss because of the improper operation. Please note to keep the instruction carefully, if any problem appears please contact us for technical supports.









safety notes


1. safety icons














Please read the meaning of safety icons below to operating in a proper way:

	Serious injury or death may happen by wrong operation with showing this signal
	Serious injury or machine damage may happen by wrong operation with showing this signal
	“attention” icon, take notes of the icon(e.g. “Mind the injury” see picture on the left
	“forbidden” icon
	“must to do” icon

2. safety notes

 danger	
	。触摸带有高电压的区域会造成人员受伤。 Please note to wait for at least 5 minutes after cut the power and pull out the plug when opening the controller
 notes	
operating environment	
	Do not use around strong electrical interference. Strong electrical interference may effect machine running state.
	Power supply voltage: $\pm 20\%$
	Environment temperature: $5^{\circ}\text{C}\sim 35^{\circ}\text{C}$
	Environment humidity: $45\%\sim 85\%$
	。 Air pressure supply should exceed machine consumption.
	Cut the power and pull out the plug on strong storm days
installation	
	Please installed by trained technician
	。 Please do not connect the electricity before the installation is done.
	Please operation with both hands
	。 Please use ground connection
	All wires should not be fixed within 25mm, electrical shock or fire may be caused by over bending wires

	Please install a cover on machine head.
-----------------------------------------------------------------------------------	-----------------------------------------

sewing procedure	
	Only operators with safety training are acceptable.
	Do not use the machine for other purposes except sewing work.
	Please wear guard glasses when operating, or else eye injury may happen because of the needle breaking.
	please cut the power under situations below: 1. Threading. 2. Needle replacement. 3. Operators away
	◦ Injury or machine damage may happen by touching any running parts under sewing work.
	Please cut the power and contact the technician when unusual noise or smell occurs under sewing work.
	Any damages please contact the suppliers for technical supports.
maintenance	
	Only trained technician maintenance are acceptable.
	Please contact the factory for electrical related maintenance supports.
	please do cut the power and pull out the plug under situations below: 1. Machine under check, adjustment and maintenance. 2. Looper, knife and other parts replacement.
	Cut the air supply before any pneumatic equipment activities.
	◦ Please read the safety notes carefully when the electric supply and pneumatic supply are connected.
	◦ Any development on machine will not under warranty.


Catalogue

1、 Controller Hardware	1
1.1 Inner Structure of Controller	1
1.2 Connector Diagram of Motor.....	1
1.3 Connector Diagram of Boards.....	2
1.4 Connector Diagram of Stepping Motor.....	3
1.5 Power Supply Specification.....	3
2、 Basic Operation Instruction.....	4
2.1 Panel Instruction.....	4
2.2 Functions on Main Panel.....	5
2.3 Functions on Main Panel under Threading.....	7
2.4 Modification of Eyelet Parameter.....	9
3、 System Setting.....	12
3.1 Setting of Basic Function.....	12
3.2 Modification of User`s Parameter.....	13
3.3 Setting of Electrical Testing.....	14
3.4 Setting of System Parameter.....	15
4、 Device Detection.....	18
4.1 Electromagnet Detection.....	18
4.2 Stepping Detection.....	19

4.3 Servo Detection.....	20
4.4 Signal Detection.....	21

1、Controller Hareware

1.1 Inner Structure




Connector Diagram of Boards (Main Controlling Board & Connector Board)



1.3

Connector Diagram of Stepping Motor Drive



1.4 Power Supply Specification

220V±15%

Power Supply Voltage: Single Phase 220V±15%

Working Current: Average Current <3A, Peak Current <5A.

2、 Basic Operation Instruction

2.1Panel Instruction







- (1) Pattern Selection**
- (2) Functions Selection**
- (3) Cable**
- (4) USD Port**
- (5) PC Communication Port**
- (6) Radio Output**
- (7) Power Supply Indicator**

2.2 Functions on Main Panel

The machine will automatically start when the power supply of control box is ON. During the START, there will be an initialization after that the controller comes to the normal working status. The operation page would be showed as below:













Sheet 1: Instruction of Icons


No.	Icons	Identification of icons	Functions
1		Left Edge / Right Edge.	Automatically moves left edge/right edge after pressing it
2		Moving Left	Move to left in one unit, under the recycled mode.
3		Moving Right	Move to right in one unit, under the recycle mode.
4		Threading	Threading by press once. After threading, press icon 8 (REST) to exit.
5		Main Presser Foot	Main presser foot. Lift up / down by pressing.
6		Small Presser Foot	Small presser foot. Lift up / down by pressing.
7		Parameter Adjusting	The parameters can be readjusted by Icon 17&18 after pressing. Exit by pressing Icon 12.
8		(REST) Reset	Mainly used to clear or remove faults.
9		Counting.	Come to counting page by pressing.

2.3 names and specifications of main interface under threading mode

No.	Icons	Button names	specifications
10		Manual	Turn the wheel by manual, feeding device moves forward stitch by stitch. Press Key 12 to exit.
11		Automatic Shift	It's used to shift between automatic recycle mode and semi-automatic recycle mode.
12		Sewing start.	Come to Sewing Mode by pressing it.
13		Functions.	Adjust the functions by pressing.
14		Patterns (backward)	Change Patterns
15		Patterns (forward)	Change patterns
16		ENTER	Confirm the parameter setting
17		Parameter Adjusting (DOWN)	Adjust parameters
18		Parameter Adjusting (UP)	Adjust parameters
19		Menu display.	all your selected patterns, sizes, speed etc are showed in this area.

Functions on the main panel under threading

Threading Mode: Come to Threading Mode by pressing Icon 1 (Threading). After the threading, exit it by pressing Icon 2 (REST).




1.

Main presser foot. Lift up / down by pressing.



2.


Small presser foot. Lift up / down by pressing



3.


Reset. Mainly used to clear or remove faults.

Counting. The figure on the up right is the production value. Come to the Setting Page by pressing it. The page will be showed as below:



5.

Manual (Icon 1). Turn the wheel by manual, feeding device moves forward stitch by stitch. Press Key 12 to exit.



6.

Automatic shift. It's used to shift between automatic recycle mode (Picture 2) and semi-automatic recycle mode (Picture 1)



图1




图2



Sewing Start. Come to Sewing Mode by pressing it, and push the foot pedal to start sewing.



2.4 Modification of Eyelet Parameters



Come to the setting page of Parameter values by pressing Icon 6. Press Icon 1 or 2 as the above picture to choose the parameters, then adjust the parameter values through Icon 4 or 5. Confirm the modification by pressing Icon 3.

No. 01 Parameter: Buttonhole length (Unit 0.5mm). Adjust the length through Icon 4 or 5, range from 15.0-25.0mm. Confirm all modification by pressing Icon 3. The previous value will be kept without confirm by Icon 3.

; Exit the Setting of Parameters by Icon 7.

Please adjust the detail setting of parameters according to the sheet as below:

Parameter Setting Table

No.	Parameter	Setting Range	Initial Value	Setting Unit	Detail setting
P01	Buttonhole Length	15.0--25.0	22.0	0.5mm	Adjusting the Length of Buttonholes
P02	Stitches distance of buttonhole	0.5--2.5	1.0	0.1mm	Adjusting Distance of each stitches
P03	Space of buttonhole	0.1—1.5	1.0	0.1mm	Adjusting Width of the Buttonhole
P04	No.s of buttonholes	2--8	4	1	Setting of Buttonhole numbers

P05	Distance between buttonholes	8.0—32.0	16.0	1.0mm	Setting of Distance between each two Buttonholes
P06	Max. speed	1500--3800	3000	100rpm	Setting Maximum speed of Main Axis Motor
P07	Rotation Angle of Bevel Motor	0-30	0	1°	Setting the Rotation Angle
P08	Round Stitches Distance	0.5—2.5	1.0	0.1mm	Adjusting Round Stitches Distance
P09	Knotting Pattern	0/1	0	1	0 flat head, 1 round head
P10	Knotting Stitches	1X,2X,3X	1	1	Setting the stitches of knot.
P11	Equal Distance between Buttonholes	0/1	0	1	Setting the EQUAL Stitches Distance between Buttonholes
P12	Distance between No. 1 & 2	4.0-32.0	4.0	1	Setting the Distance between No. 1 & 2 Buttonholes
P13	Distance between No. 2 & 3	4.0-32.0	4.0	1	
P14	Distance between No. 3 & 4	4.0-32.0	4.0	1	
P15	Distance between No. 4 & 5	4.0-32.0	4.0	1	
P16	Distance between No. 5 & 6	4.0-32.0	4.0	1	
P17	Distance between No. 6 & 7	4.0-32.0	4.0	1	
P18	Distance between No. 7 & 8	4.0-32.0	4.0	1	


3、System Setting

To meet the detail requirements, users may setting the working parameters through the following setting page.

3.1 Setting of Basic Function



Press Key F as the above marked, come to the following page:



1. Key 1 ; check the version
2. Key 2: restart to zero
3. Key3: back-ups of patterns or parameters
4. Key 4: electric testing
5. Key 5: revise system parameters
6. Key 6: check the manual
7. Key 7: check the error or faults
8. Key 8:to default setting

3.2

Modification of Users` Parameter

Revise the Users` Parameters by Pressing Icon 5, the page would be showed as below:

项 目 (ITEM)	值(VALUE)	项 目 (ITEM)	值(VALUE)
U001 送布方式 Feeding Methods	1	U002 圆头速度 Eyelet RPM	2000
U003 套结速度 BarTack RPM	2000	U004 慢起针针数 Slow Stitches	1
U005 慢起针速度 Slow Stitches RPM	2000	U006 圆头补偿 Eyelet is -5 to 1	0
U007 y轴送布补偿 y Feeding MakeUp	0	U008 Z轴补偿 Z MakeUp	0
U009 剪线开关 TrimmingSwitch	ON	U010 松线开关 ThreadSlack Switch	ON
U011 扫线开关 SwingLine Switch	ON	U012 圆头偏移量 Eyelet Offset	0

U001: adjusting feeding methods

U002: adjusting eyelet speed

U003: adjusting knotting speed

U004: adjusting numbers of slow stitches

U005: adjusting speed of slow stitches

U006: adjusting offset of round head

U007: adjusting feeding offset of Y axis.

U008: adjusting offset of Z axis

U009: cutting switch


U010: thread loosng switch

U011: thread wipe switch

U012: adjusting the offset.

3.3 Setting of Electric Testing

Press Icon 4 to Electric Testing as below:




:

No.	Icon	Function	Details
1		Electromagnet Detection	Come to the electromagnet detecting page by pressing it.
2		Stepping Detection	Come to the detecting page of x, y, z, u, w axis by pressing it.
3		Servo Detection	Come to servo detecting page by pressing it
4		Signal Detection	Come to signal detecting page by pressing it
5		System Parameter	Revise system parameter
6		Initialization	Initialize the system parameters
7		Operating Life	Revise the using life
8		Revise password	Revise the password
9		WC Page	Come to WC page by clicking it to exit the software
10		Off-line	Work automatically through off-line by pressing it.

3.4 Setting of System Parameter

Press Icon 4 on Function Setting Page to Electric Testing Page, then input password to the system setting by pressing Icon 5



Functions of icons

No.	Icons	Functions
1	Max. Speed	Setting the maximum speed
2	Air Valve Status	Allow or forbid to open the valve
3	10-500 Closing Time of Threading	Setting the time of stopping threading. 10 is Minimum, 500 is Maximum.
4	Stopping Position of Main Axis	Setting the Stopping Position of Main Axis
5	Polarity of Emergency Stopping Switch	Unchange or reverse the polarity of emergency stopping switch
6	Synchronized Timing of Feeding	Choose the Synchronized Timing of Feeding
7	Open Time of Thread Wiper	Setting of the starting time of thread wiper
8	Time of Needle down	Setting the time of needle down of the main axis
9	Closing time of thread wiper	Setting the ending time of thread wiper
10	X original point	Setting the X original point
11	Y original point	Setting the Y original point
12	Open time of thread cutting	Setting the open time of cutting thread
13	Open time of thread loosening	Setting the open time of thread loosening
14	10-500 Closing time of thread	Setting the time of thread loosening. 10 is Minimum, 500 is Maximum.

	loosing	
15	Electromagnet of main presser foot PWM	Setting the duty ratio of electromagnet presser foot
16	Thread loosing electromagnet PWM	Setting the duty ratio of thread loosing electromagnet.
17	Polarity of X sensor	Unchange or reverse the polarity of X sensor
18	Polarity of Y sensor	Unchange or reverse the polarity of Y sensor
19	Verify of stopping position	Setting the verifying point of stopping position of main axis.
20	X axis offset	Setting the offset of X axis
21	Starting time of main axis	Setting the starting time of main axis
22	Polarity of Z axis sensor	Unchange or reverse the polarity of Z-axis sensor
23	Natural status of main presser foot	Lift or put down the main presser foot when starting the program or ending the sewing.
24	Speed of threading	Setting the speed of thread cutting
25	Switch of process/testing	Setting of machine process or testing
26	Pause testing	Setting the pause time of testing
27	Z axis original point	Setting the original point of Z axis.
28	30-300 Time of presser foot	Setting the time of presser foot,30 is Minimum, 300 is Maximum.
29	50-450) Verify the X speed	Setting the verifying factor of X speed,50 is Minimum, 450 is Maximum.
30	(100-700) Verify the Y speed	Setting the verifying factor of y speed,100 is Minimum, 700 is Maximum.
31	(50-150) Verify the time of Y speed up	Setting the verifying factor of Y accelerating time
32	Motor Original point of U axis	Setting the original position of motor on U axis
33	V axis original point	Setting the original position of V axis
34	Motor drive ratio of U axis	Setting the drive ratio of motor on U axis
35	(50-500)	.

	Verifying the initial speed of U axis	Setting the verifying factor of initial speed on U axis.
36	(50-500) Verify the target speed of U axis	Setting the verifying factor of target speed on U axis
37	50-500) Verify the accelerating time of U axis	Setting the verifying factor of accelerating time on U axis
38	clockwise0- anticlockwise1) Rotation direction on U axis	Setting the rotation direction. 0 is clockwise, 1 is anticlockwise
39	Polarity of sensor on U axis	0-unchanged 1-reverse
40	Foot pedal types (1,2)	Setting the foot pedal, the default is 2
41	(50-200) Verify the X accelerating time	Setting the verifying factor of X axis accelerating time

Device Detection

Please enter the Testing Page when any faults occurs in the controlling system. Check the main device of input and output independently so that find out the reasons of the faults.

As described above, the Testing Page would be appeared the Electric Testing Page


4.1

Electromagnet Detection

Come to Electromagnet Detection Page (Picture 2) by pressing Icon 1 "Electromagnet Detection"









(picture 1)




(picture 2)

: Functions of the Icons


No.	Icons	Function
1		detection for main presser foot
2		detection for small presser foot
3		detection for threading switch
4		detection for thread loosing switch
5		detection for thread wiper switch
6		detection for rotary cylinder

4.2 Stepping Detection

Come to Stepping Detecting Page (Picture 2) by pressing Icon 2 "stepping detection"



(picture 1)



(picture 2)

As the picture showed, users can make the detection to the forward and reverse of x,y, z, u,w axis of electronic sewing machines and also the stepping speed




4.3 Servo Detection

Come to Servo Testing Page (Picture 2) by pressing Icon 3 "Servo Detection"







(picture1)



(picture2)

: Functions of Icons

No.	Icon	Functions
-----	------	-----------


1		make a clockwise detection to the motor
2		Setting the turns number that motor is running
3		make a anticlockwise detection to the motor
4		Setting the rotate speed of motor

4.4 Signal Detection

Come to Servo Detection Page (Picture 2) by pressing Icon 4 "Signal Detection"




(picture1)



(picture2)

As the above picture showed, press  to make a detection for signal.

Setting the upper stopping position by pressing , but the upper stopping position should be adjusted first.